

FORTISEAL™

A GUIDE TO INSTALLATION

Fortifiber® **FortiSeal** comes in 1/2 and 3/4 inch sizes and is used to flash pipe penetrations in weather resistive barriers. It is manufactured from a high-strength, high-stretch polyolefin to fit a wide range of pipe diameters.

PipeFlash is sized 8 1/2" x 11", and includes two pipe fittings per sheet. Thickness is 10 mils.



Step 1:

Make an "X" cut in the weather resistive barrier before placing it over the pipe penetration.



Step 2:

Cut a flap above the penetration using 45 degree angles.



Step 3:

Select either the 1/2 or 3/4 inch PipeFlash, bearing in mind that it will stretch considerably. Slide the PipeFlash beneath the flap and lap over the weather resistive barrier in a weatherboard fashion.



Step 4:

Tape the vertical edges with **Fortifiber Sheathing Tape**.



**Fortifiber Building
Systems Group®**

Protecting Your World from the Elements®

NATIONAL SALES OFFICE - Fernley, NV

(04/20/12)

Call 1-800-773-4777 nationwide for technical assistance or visit our website at www.fortifiber.com